# Superior mixing - Liquid, Gas and Powder

# IM 10 Rotary Jet Mixer

The patented IM 10 Rotary Jet Mixer (RJM) does not only mix fast, efficient and uniform but creates also the necessary process flexibility that makes it easy to switch to new product formulations with diverse viscosities, densities and volumes. Besides classic liquid to liquid mixing the RJM is excellent for gas and powder dispersion plus a superb tank cleaning machine.

#### Applications

Process and storage vessels between 1-10 m<sup>3</sup> used in a wide range of industries such as: beer & beverage, food & ingredients, home & personal care, health care, biotech and chemical industry etc.

#### Operation

Secure that the mixer is positioned in the correct level and submerged into the liquid before round pumping or when adding any additional products from any up-stream pipe works.

## TECHNICAL DATA

Lubricant:	Self-lubricating with the mixing/cleaning fluid
Standard thread:	0 0
Min. tank opening:	See dimension drawings
Pressure	
Working pressure:	2-8 bar
Recommended pressure	
during mixing:	2-6 bar
Recommended pressure	
during CIP:	4-8 bar



## PHYSICAL DATA

#### Materials

Materials:	AISI 316L, AISI 316, SAF 2205 (UNS 31803), EPDM, PEEK, PVDF, PFA, Ceramics
Weight:	5.1 kg
TemperatureMax. working temperature:Max. ambient temperature:	
Certificates	

2.1 material certificate ATEX.

#### Benefits

Using the IM 10 Rotary Jet Mixer makes it possible, at a modest investment, to perform fast and efficient mixing in a sanitary system. In traditional systems, using propeller mixers, a rotating shaft penetrates the tank wall, and a mechanical seal and a gear box are installed. With the Rotary Jet Mixer technology the shaft, seal and gearbox are eliminated, and a more sanitary design is obtained. With the Rotary Jet Mixer can also be used for gas dispersion. The IM 10 can furthermore be used for efficient CIP when the tank is empty, saving liquid, chemicals and energy compared to a fixed spray ball CIP system.



4.3